

2014 – Present Twin Cooled Cup Holder

Installation Instructions

Using your hands or a non-marring tool, carefully pry the cover of the lower fairing.





Once placed, tilt the glove box cover up, and turn the key (or the tab on the keyless lock) to lock it into place.



